Using SIM Card with The Grid 2:

Insert Sim into PowerBox MOTION (see pictures below)

Insert SIM card here

2. Once the SIM card has been inserted you will need to change some setting in the Grid 2 to enable the software to access the Sim card.

- Open the desired Grid Set and on the toolbar select EDIT → USER SETTINGS

- Select WORKSPACE settings → Mobile Phone

- Change the country code to Australia

- Select 'Com 3' from the Com Port List.

- Select OK.