




1. Go to Device Manager (search in start menu for it)



2. Right click on Gobi in modems
3. Take note of the com port number under the modem tab
- 4 In Grid 2 User Settings go to Workspace then Mobile Phone
5. change country to aust and enter com port number





5. Change country to Australia and enter COM port number

6. Click TEST setting and if done correctly all boxes will have ticks.

